



Automatic deblistering

## **Key features:**

- Automatic unstripping of tablets, pills and capsules
- Patented press-out system
- Table top
- Adjustable roller pressure
- Large variety of blisters possible
- High press-out rate
- Cartridge height for approx. 60 blisters
- Easy and quick to clean



**Deblimatic® A19** 

The patented press-out system in combination with the cassette is the core of the Deblimatic® deblister machines. The simple interchangeable cassette system enables using multiple cassettes.

The Deblimatic® A19 is supplied with two rollers of different rubber hardness grades. The soft roller is particularly suitable for squeezing out capsules without damaging the capsules.

# Set-up tool Using the sr

Using the specifically developed set-up tool, the cassette can be set up quickly and flawlessly.



Set-up tool 2.4

## **Indicative capacity:**

Choice of three speeds depending on the medication to be pressed out:

- 26 cycles/min e.g. for very fragile medication
- 35 cycles/min e.g. for capsules and sensitive medication
- 50 cycles/min e.g. for regular medication

#### **Electrical data:**

Voltage: 220 - 240 Volt, 50Hz

Power: 250 W

Fuse: 16 Amp circuit breaker

Operating temperature: 10 - 30 °C

Dimensions: L x W x H = 600 x 450 x 700 mm

Weight: approx. 35 kg

### **Trolley**

To use the Deblimatic A19 as efficiently as possible, LO&T has developed the Trolley.

Characteristics:

- Stable construction of durable stainless steel
- Small footprint
- Clear and protective storage for all necessities.



Address : Willem Barentszstraat 7d

7825 VZ Emmen, The Netherlands

Tel. : +31 (0)591 391 064 Mobile : +31 (0)626 672 930

www.langemaat.eu

Bank : Rabobank Emmen
IBAN : NL17 RABO 0318 0837 01

Reg. number : 75248123

VAT number : NL8602.07.213.B01

info@langemaatontwikkelingentechniek.nl}