

**High speed fully automatic deblistering machine****Key features:**

- Automatic unstripping of tablets, pills and capsules
- Patented press-out system
- Table top
- Adjustable roller pressure
- Large variety of blisters possible
- High press-out rate
- Cartridge height for approx. 60 blisters
- Easy and quick to clean

**Deblimatic® HS22**

The patented press-out system in combination with the cassette is the core of the Deblimatic® deblistering machines. The simple interchangeable cassette system enables using multiple cassettes.

The Deblimatic® HS22 is supplied with two rollers of different rubber hardness grades. The soft roller is particularly suitable for squeezing out capsules without damaging the capsules.

**Set-up tool**

Using the specifically developed set-up tool, the cassette can be set up quickly and flawlessly.

**Set-up tool 2.4****Indicative capacity:**

Choice of three speeds depending on the medication to be pressed out:

- 28 cycles/min e.g. for very fragile medication
- 48 cycles/min e.g. for capsules and sensitive medication
- 66 cycles/min e.g. for regular medication

**Electrical data:**

Voltage: 220 – 240 Volt, 50Hz

Power: 250 W

Fuse: 16 Amp circuit breaker

Operating temperature: 10 – 30 °C

Dimensions: L x W x H = 600 x 450 x 700 mm

Weight: approx. 35 kg

**Trolley**

To use the Deblimatic HS22 as efficiently as possible, LO&T has developed the Trolley.

Characteristics:

- Stable construction of durable stainless steel
- Small footprint
- Clear and protective storage for all necessities.



Address : Willem Barentszstraat 7d  
7825 VZ Emmen, The Netherlands

Tel. : +31 (0)591 391 064

Mobile : +31 (0)626 672 930

[www.langemaat.eu](http://www.langemaat.eu)

Bank : Rabobank Emmen

IBAN : NL17 RABO 0318 0837 01

Reg. number : 75248123

VAT number : NL8602.07.213.B01

[info@langemaatontwikkelingentechniek.nl](mailto:info@langemaatontwikkelingentechniek.nl)