

Fully automatic deblister machine with counting and filling function

Deblimatic® L16

Automatic deblistering

Key features:

- Automatic unstripping of tablets, pills and capsules
- Patented press-out system
- Adjustable roller pressure
- Large variety of blisters possible
- High press-out rate
- Magazine height for approx. 90 blisters
- Automatic counting and filling unit
- Dust collection system



Deblimatic® L16



Detail press-out system

The patented press-out system in combination with the cassette is the core of the Deblimatic® deblister machines. The simple interchangeable cassette system enables using multiple cassettes.



The Deblimatic® A19 is supplied with two rollers of different rubber hardness grades. The soft roller is particularly suitable for squeezing out capsules without damaging the capsules.



Automatic counting and filling system

Of course, the counted medication can also be filled in jars instead of pouches. The filling unit can be easily set in the program.

Set-up tool

Using the specifically developed set-up tool, the cassette can be set up quickly and flawlessly.



Set-up tool 2.4

Indicative capacity:

Variable speed up to 60 cycles/min

Counting error: maximum 0,5%

Electical data:

Voltage: 220 – 240 Volt, 50Hz

Amp Power: 2,7 kW

Fuse: 16 Amp automatic

Operating temperature range: 10 – 30 °C

Dimensions: L x W x H = 1100 x 450 x 1650 mm

Weight: approx.. 80 kg

Address : Willem Barentszstraat 7d
7825 VZ Emmen, The Netherlands

Tel. : +31 (0)591 391 064

Mobile : +31 (0)626 672 930

www.langemaat.eu

Bank : Rabobank Emmen

IBAN : NL17 RABO 0318 0837 01

Reg.-number : 75248123

VAT-number : NL8602.07.213.B01

info@langemaatontwikkelingentechniek.nl