

Semi-automatic deblister machine

Key features:

- Unstripping of tablets, pills and capsules
- Patented press-out system
- Table top
- Adjustable roller pressure
- Large variety of blisters possible
- High press-out rate
- Easy and quick to clean



Deblimatic® SA18

The patented press-out system in combination with the cassette is the core of the Deblimatic® deblister machines. The simple interchangeable cassette system enables using multiple cassettes.

The Deblimatic® SA18 is supplied with two rollers of different rubber hardness grades. The soft roller is particularly suitable for squeezing out capsules without damaging the capsules.

Set-up tool

Using the specifically developed set-up tool, the cassette can be set up quickly and flawlessly.



Set-up tool 2.4

Indicative capacity:

Choice of two speeds depending on the medication to be pressed out:

- 25 cycles/min e.g. for capsules and fragile medication
- 40 cycles/min e.g. for regular medication

Electrical data:

Voltage: 220 – 240 Volt, 50Hz

Power: 200 W

Fuse: 16 Amp circuit breaker

Operating temperature: 10 – 30 °C

Dimensions: L x W x H = 375 x 400 x 450 mm

Weight: approx. 30 kg

Trolley

To use the Deblimatic SA18 as efficiently as possible, LO&T developed the Trolley.

Characteristics:

- Stable construction of durable stainless steel
- Small footprint
- Clear and protective storage for all necessities.



Address : Willem Barentszstraat 7d
7825 VZ Emmen, The Netherlands

Tel. : +31 (0)591 391 064

Mobile : +31 (0)626 672 930

www.langemaat.eu

Bank : Rabobank Emmen

IBAN : NL17 RABO 0318 0837 01

Reg. number : 75248123

VAT number : NL8602.07.213.B01

info@langemaatontwikkelingentechniek.nl